

TomTom App

Contents

Getting Started	5
Start TomTom App	5
Updating your TomTom App	5
GPS reception	5
Planning a Route	6
Planning a route	6
Route summary	7
Sharing your route	7
Other destination options	7
Finding an alternative route	9
Planning a route in advance	9
Setting a reminder	10
Driving View	11
The Driving View	11
Moving around in the Driving View	12
Setting the volume	12
Quick Access Toolbar	13
Map settings	13
Advanced Lane Guidance	14
About Advanced Lane Guidance	14
Route Options	15
About Route Options	15
Minimise Delays	15
Find Alternative	15
Calculate Alternative	16
Recalculate Route	16
Avoid Roadblock	16
Travel Via...	17
Avoid Part of Route	18
Route Demo	18
Clear Route	18
Instructions	18
Map of Route	18
Settings	19
Change Settings	19
Set Home Location	19
Manage Favourites	19
Voice	19
Alerts	20
Audio	20
Map	21

Route planning	21
Distance Units	22
About	22
Advanced.....	22
Reset	23
Main Menu	25
The Main Menu.....	25
Navigate To menu	26
Return to Driving View.....	27
Browse Map	28
Browsing a Map.....	28
Markers.....	28
Selecting Items on the Map.....	28
Map Toolbar	30
Map Corrections with TomTom Map Share	32
About TomTom Map Share	32
Map corrections	32
Switching Map Share on and off	32
Downloading and sending map corrections	32
Reporting a map error	33
Types of map correction.....	33
Points of Interest (POIs)	35
About POIs	35
Navigating to a POI	35
Finding a POI on the Map Browser	37
Showing POIs on the map.....	38
Selecting which POIs to show on the map.....	38
Help Me	39
About Help Me.....	39
Using Help Me to phone a local service	39
Favourites	40
About Favourites	40
Creating a Favourite.....	40
Using a Favourite	41
Changing the name of a Favourite	41
Changing the order of your Favourites.....	42
Deleting a Favourite	42
Traffic Information	43
TomTom HD Traffic.....	43
Using traffic information.....	43
Checking traffic incidents in your area	46
Traffic incidents	47
Regional availability.....	48

Buying a new Traffic subscription.....	48
Checking your Traffic subscription	48
Renewing your Traffic subscription	48
Speed Cameras	49
About Speed Cameras	49
Types of speed cameras and safety-related features	49
Frequency of speed camera updates.....	51
Report a speed camera	52
Remove a speed camera	52
Regional availability.....	52
Settings for Speed Cameras Alerts	52
Buying a new Speed Cameras subscription	52
Checking your Speed Cameras subscription	53
Renewing your Speed Cameras subscription	53
TomTom Local Search with Google	54
About TomTom Local Search with Google	54
Using local search	54
'Add to TomTom'	56
About 'Add to TomTom'.....	56
Using the 'Add to TomTom' button	56
Addendum and Copyright	57

Getting Started

Start TomTom App



TomTom

Tap this button on your iPhone, iPod or iPad to start TomTom App.

The language used for buttons and menus in TomTom App is the same as the language you selected in your Apple device settings.

If a route is already planned TomTom App shows [The Driving View](#), and navigation starts immediately. If no route is planned [The Main Menu](#) is shown.

Note: If your TomTom App supports Advanced voices in your language you are given the option to download an Advanced voice when you start TomTom App for the first time. See [Voice](#) for more information.

TomTom App works the same on the iPhone, the iPod touch and the iPad. The iPad has a much larger screen which means that menus appear on the Driving View instead of as full-screen menus. See [Driving View](#) for more details.

Updating your TomTom App

If you have an old version of TomTom App on your Apple device, you must update to the latest version of TomTom App before continuing to read this guide.

To download and update your Apple device with the latest version of TomTom App, go to the Apple App Store.

GPS reception

The iPod touch, the iPad (Wi-Fi only models), and the original iPhone do not include a GPS receiver. To use these devices for navigation, you need to connect them with a GPS accessory device.

Note: Using a GPS accessory device can also improve the accuracy of GPS in other iPhone models.

When you first start TomTom App, it may need a few minutes to find your GPS position and show your current location on the map.

To make sure you have good GPS reception, you should use your device outdoors. Large objects such as tall buildings can sometimes interfere with reception.

Important: TomTom App cannot give you route instructions until it has GPS reception.

If your device has no GPS reception, TomTom App uses positioning information from WiFi networks or mobile phone towers. This information is used for route planning and to determine your approximate location.

Planning a Route

Planning a route

Important: In the interest of safety and to reduce distractions while you are driving, you should always plan a route before you start driving.

To plan a route with TomTom App, do the following:

1. Tap the screen to open the Main menu.
2. Tap **Navigate To....**



3. Tap **Address.**



Tip: The first time you plan a route, you are asked to select a country, state or region. Your selection is saved and used for all future routes until you change this setting.

You can change this setting by tapping the flag before you select a city.

4. Start to type the name of the town you want to go to.

As you type, the names of the towns that match what you have typed are shown. When your destination appears in the list, tap the name of the town to set the destination.

Tip: For destinations in the UK and the Netherlands, you can also type in the postcode of your destination. Select the postcode from the list shown to display a list of streets in that postcode.

5. Start to type the name of the street.

Just as for place names, the names of the streets that match what you have typed are shown. When your destination appears in the list, tap the name of the street to set the destination.

Tip: The keyboard automatically hides when you scroll the search results. This allows you to see more results on the screen.

6. Enter the house number and then tap **Select.**

You can also select the point where two streets meet by tapping **Crossing.**

The route is calculated.

By default, the fastest route is planned. You can change this setting in the Route Planning settings menu.

If IQ Routes is available on your map, this information is used to plan the best possible route taking into account the real average speeds measured on the roads.

7. When the new route is shown, tap **Done.**

TomTom App starts to guide you to your destination using spoken instructions and on-screen directions.

Route summary

After you plan a route, a summary of the route is shown.

The route summary shows an overview of your route on the map and the estimated travel time including delays caused by busy roads. If you have a TomTom HD Traffic subscription, the estimated travel time includes delays due to traffic incidents on your route.

The bottom of the summary screen shows the following options:

- Tap **+1** to add a Travel Via stop. See [Travel Via...](#) for more details.
- Tap **Options** to change or view your route. See [Route Options](#) for more details.
- Tap **Done** to start route guidance.

You can view the route summary at any time by tapping the right-hand side of the status bar at the bottom of the Driving View.



Sharing your route

After planning a route, you can share a summary of your route with friends and colleagues via email.

To share your route, make sure your device is set-up to send emails and then do the following:

1. Tap **Route Options** in the Main menu.
2. Tap **Share My Route**.
3. Enter an email address for everyone you want to see the route.
4. Tap **Send**.

A summary of your route is sent via email. The email contains links which allow recipients to view the starting point and destination of your route using TomTom App, iPhone Maps application or an Internet browser.

Other destination options

When you tap **Navigate To** in the Main menu, you can select your destination in the following ways:



Home

Tap this button to plan a route to your Home location.
To set your Home location, tap **Home** in the Settings menu.



Favourite

Tap this button to select a Favourite as your destination or to edit your favourites. See [Favourites](#) for more details.



Address

Tap this button to enter an address as your destination. To navigate to a postcode, tap the **Postcode** button at the top of the screen to display the Postcode screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



Recent Destination

Tap this button to select your destination from a list of places you have recently used as destinations. These also include your Travel Via stops.



Local Search

Tap this button to run an Internet search of the local area and use the location of one of the search results as your destination. See [TomTom Local Search with Google](#) for more details.



Point of Interest

Tap this button to navigate to a Point of Interest (POI).



Contact

Tap this button to plan a route to the address of a contact in your address book.



Photo

Tap this button to select a photo from your iPhone gallery and use it as your destination.


Note: Only photos that contain location data can be used. This feature can be enabled in the iPhone Camera application.



Postcode

Tap this button to enter a postcode as your destination. To navigate to an address, tap the **Address** button at the top of the screen to display the Address screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



Tap this button to select a point on the map as your destination using the Map Browser. See [Browse Map](#) for more details.

Point on Map



Tap this button to enter the map coordinates of a location on the map as your destination.

Coordinates

Finding an alternative route

Once you have planned a route, you may want to change something about the route, without changing your destination. You may want to do this for one or more of the following reasons:

- You can see a roadblock or a line of traffic ahead.
- You want to travel via a particular location to pick someone up, stop for lunch or fill up with petrol.
- You want to avoid a difficult junction or a busy narrow street.

For more details, see [Find Alternative](#).

Planning a route in advance

You can use TomTom App to plan a route in advance by selecting your starting point and your destination.

Here are some reasons why you might want to plan a route in advance:

- Find out how long a journey is going to take before you start.
You can also compare journey times for the same route at different times of the day or on different days of the week. TomTom App uses IQ Routes when planning a route. IQ Routes calculates routes based on the real average speeds measured on roads.
- Check the route of a journey you are planning.
- Check a route for someone who is coming to visit you and share the route with them.

To plan a route in advance, do the following:

1. Tap the screen to open the Main menu.
2. Tap **Advanced Planning**.



3. Select the starting point for your journey in the same way that you would select your destination.
4. Set the destination for your journey.
5. Choose the type of route that should be planned.
 - **Fastest** - the route which takes the least time.
 - **Eco Route** - the most fuel-efficient route.
 - **Shortest** - the shortest distance between the locations you set. This may not be the quickest route, especially if the shortest route is through a town or city.

- **Avoid Motorways** - a route which avoids motorways.
 - **Walking Route** - a route designed for making the journey on foot.
 - **Bicycle Route** - a route designed for making the journey on a bicycle.
 - **Limited Speed** - a route for a vehicle which can only be driven at a limited speed. You have to specify the maximum speed.
6. If IQ Routes is supported by your map, you can choose when you will make the journey you are planning. You can set the date and time in 5 minute intervals.
- TomTom App uses IQ Routes to work out the best possible route at that time, using the real average speeds measured on roads. In this way you can compare how long a journey takes at different times of day, or on different days of the week.
7. TomTom App plans the route between the two locations you selected.

Setting a reminder

You can use TomTom App to set a reminder for a route that you have planned in advance. The reminder is added to your iPhone calendar and set to alert you a short time before you need to depart. The reminder contains a link which opens TomTom App and automatically plans the route.

To set a reminder, do the following:

1. Select **Options** in the Route Summary view.
2. Tap **Add to Calendar**.
3. Add any additional notes you want to save in the reminder.
4. Tap **Save**.

The reminder is saved in your iPhone calendar.

Driving View

The Driving View



1. Shows the quick access toolbar. See [Quick Access Toolbar](#) for more details.
2. The top status bar shows the following information:
 - the name of the next street on your route
 - the total delay found on your route by TomTom HD Traffic
 - other messages, such as "Poor GPS Reception".
3. Your current position.
4. TomTom HD Traffic button.
Tap this button to buy a TomTom HD Traffic subscription or to open the traffic sidebar. See [Traffic Information](#) for more details.
5. The remaining distance of your journey and your current speed. If known, the speed limit is also shown.
6. Navigation instruction for the road ahead.
Tap this area to open the volume control and to repeat the previous instruction.

7. TomTom HD Traffic information about the traffic incident that this box points to on the traffic sidebar.
8. The remaining journey time and the estimated arrival time.
Tap this area to open the Route Summary screen. See [Route summary](#) for more details.
9. TomTom HD Traffic sidebar.

Tip: If you have a TomTom Speed Cameras subscription you also see symbols for speed cameras. See [Speed Cameras](#) for more information.

Moving around in the Driving View

When you plan a new route, you are shown the Driving View together with detailed information about your current location.

Tap the centre of the screen at any time to open the Main menu.

Zoom by tapping the screen twice with one finger to zoom in, or tap once with two fingers at the same time to zoom out.

You can also zoom in and out by placing your fingers on the screen and pinching them together and stretching them apart.

iPad-specific features

TomTom App on the iPad has two extra buttons in the top menu bar:



The buttons have the following functions:



Tap this button to open and close the Main menu. You can also tap the screen to open and close the Main menu.



Tap this button to open a quick link to navigate to home, a Favourite, or a recent destination. When you tap one of the items TomTom App calculates a route to navigate you there.

Setting the volume

Tap the left-hand side of the status bar in the Driving View to show the volume control.




Move the slider from left to right to increase the volume for both music and voices at the same time.

Move the slider all the way to the left to mute all sounds from TomTom App. When the sound is muted, the mute sound indicator is shown in the bottom left corner of the Driving View.

Quick Access Toolbar

Tap the quick access toolbar button to display the following option buttons:




Tap the music button to play or pause music.

You can tap play/pause, next and previous to control the music track that is currently playing.



The volume control also appears at the bottom of the screen to let you set the volume for both music and voices.

The buttons disappear on their own after a few seconds or you can tap the Quick Access Toolbar again to make the buttons disappear immediately.




Tap this button to switch off voice guidance. You will no longer hear spoken route instructions but you will still hear information such as traffic information and warnings.

If the voice is muted, this button changes to **Enable Voice**. Tap the button again to turn voice instructions back on.

When voice instructions are disabled, the voice disabled indicator is shown in the bottom left corner of the Driving View.

To mute all sounds from TomTom App tap the navigation instruction area on [The Driving View](#) and slide the volume slider to the left.



Tap this button to use night colours on the menus and maps. If night colours are being used, this button changes to a sun symbol. Tap the button again to switch back to day colours.



Tap this button to use a 2D map in the Driving View.

If the 2D map is being used, this button changes to **3D**. Tap the button again to use the 3D map.

Map settings

You can change the way the map looks and behaves as you drive, and change what you see on the map. See [Map](#) in the **Settings** menu for more details.

Advanced Lane Guidance

About Advanced Lane Guidance

TomTom App helps you prepare for motorway exits and junctions by showing you which lane you should be in.

Note: Advanced Lane Guidance is not available for all junctions or in all countries. To find out if Advanced Lane Guidance is available in your country, go to tomtom.com/iphone.

For some exits and junctions, an image shows the lane you should be in. To turn the images off, switch **Lane images** off in the Advanced Settings menu.



For other exits and junctions, TomTom App shows the lane you should take in the status bar.



Route Options

About Route Options

You can find out more information about your route, or change the route using the route options.



Route Options

You can open the route options as follows:

- Tap **Route Options** in the Main menu.

Tip: **Route Options** is only available when you have planned a route.

- Tap **Options** on the Route Summary screen after you plan a route.
- Tap the right hand section of the status bar in the Driving View to open the Route Summary screen, then tap **Options**.

Minimise Delays



Minimise Delays

Tap this button to re-plan your route based on the latest traffic information.

This button is only available if you have a subscription to TomTom HD Traffic.

Find Alternative



Find Alternative

Find Alternative lets you change your route without changing your destination.

In the **Route Options** menu, tap **Find Alternative** to display the following options:

- [Calculate Alternative](#)
- [Recalculate Route](#)
- [Avoid Roadblock](#)
- [Travel Via...](#)
- [Avoid Part of Route](#)

Calculate Alternative



**Calculate
Alternative**

Tap **Calculate Alternative** to calculate an alternative to the current route.

Apart from the roads near your current position and near your destination, a new route is calculated using totally different roads to reach your destination. This is an easy way of planning different route to the same destination.

TomTom App looks for another route from your current location to your destination.

If you decide you would prefer to use the original route after all, tap **Recalculate Route**.

Recalculate Route



Recalculate Route

Tap this button to return to the original route. This ignores any previous instructions you have given to avoid roadblocks or travel via a particular location.

Avoid Roadblock



Avoid Roadblock

Tap this button if you can see a roadblock or a line of traffic ahead. You then have to choose how much of the route ahead you want to avoid.

Choose from the different options available. TomTom App recalculates your route avoiding the section of the route for the distance you selected.

Don't forget that once a new route is calculated, you may have to turn off the road you are on very soon.

If the roadblock suddenly clears, tap **Recalculate Original** to return to your original route.

Travel Via...



Travel Via...

Tap this button to change your route so that it passes a particular location, perhaps to pick someone up on the way. You can add up to five extra stops along your route.


You can also open **Travel Via...** by tapping the **+1** flag at the bottom of the route summary.

When have not yet entered a stop, the **Travel Via...** menu opens. When you have entered a stop, tap the **+** symbol at the bottom of the Travel Via screen to add another stop. You can add up to five stops.

Tip: You choose the stop in the same way as you choose a destination. This means you can select from all the same options that are offered when you choose a destination, for example **Address**, **Favourite**, **Point of Interest** or **Point on Map**.

Tap a stop in the Travel Via list to see more information about the stop. On the information screen you can set the **Alert On Arrival** to on or off.

Tip: You hear an Alert sound when you reach the Travel Via stop. You can change the sound in [Alerts](#).

To change the order of the Travel Via stops you have entered, tap the **Edit** button, then drag a stop using the order symbol  on the right of the stop to its new position. Tap the **Done** button to close the edit screen.

To delete a Travel Via stop you have entered, use one of the following methods:

- Tap the **Edit** button, then tap the stop sign that appears to the left of the stop. Tap the red **Delete** button that appears on the right of the stop. Tap the **Done** button to close the edit screen.
- Swipe across the stop to show the red **Delete** button on the right of the stop. Tap the **Delete** button to remove the stop.

When you have added Travel Via stops, tap the **Done** button at the top of the Travel Via screen. TomTom App calculates a new route to your destination that passes the stops you chose. A flag appears in the Driving View at each of your Travel Via stops. Unlike at your final destination, TomTom App only gives a sound alert when you reach a Travel Via stop.

Avoid Part of Route



Avoid Part of Route

Tap this button to avoid a part of the route. Use this button if you see that your route includes a road or junction you don't like, or which is well-known for traffic problems.

You then choose the road you want to avoid from a list of the roads on your route.

Route Demo



Route Demo

Tap the **Route Demo** button to watch a demo of the journey. To stop a demo, tap **Stop Demo** in the **Route Options** menu when a demo is running.

Clear Route



Clear Route

Tap this button to clear the currently planned route.

Instructions



Instructions

Tap this button for a list of all the turn instructions on the route.

Map of Route



Map of Route

Tap this button to see an overview of the route using the Map Browser.

Settings

Change Settings

To change the way TomTom App looks and behaves, tap **Change Settings** in the Main menu.

Set Home Location

Tap this option to set or change your **Home Location**. Select the address for your home location in the same way that you select a destination.

Your home location can be somewhere you often visit, such as your office. This feature provides an easy way to navigate there by tapping the **Home** button in the **Navigate To** menu.

Manage Favourites

Tap this button to go to Favourites where you can add to, edit and delete your favourites. See [Favourites](#) for more details.

Voice

Tap this option to select the voice used for instructions. You can choose from three different kinds of voices.

Note: A recorded human voice can say instructions but is unable to read aloud street names. If you would like street names to be included with instructions, you must select an **Advanced Voice**.

- **Celebrity Voices**

These are recorded by an actor. Use a celebrity voice to make your journey more fun and entertaining. Tap the **Celebrity Voices** button to choose a celebrity voice or purchase a new celebrity voice.

- **Advanced Voices**

TomTom App uses Advanced voices to provide spoken instructions while you are driving. An Advanced voice gives driving instructions and pronounces street names, signs and status messages. You can only use an Advanced voice that is in the language your Apple device uses.

When you start TomTom App for the first time you are given the option to download an Advanced voice.

To download extra Advanced voices tap **Download**. When it has downloaded tap **Use It Now** to use the voice.

Note: Advanced voices are not available in all languages.

- **Basic Voices**

A basic voice reads the driving instructions but does not read the street names, road numbers or signs.

You can select a basic voice in any language. The language used for menus and buttons does not change if you select a voice in a different language.

When you select a voice, a sample of that voice is played.

Alerts

Tap this option to switch on safety alerts.

Speed Camera

Adjust this setting to switch on visual alerts in the Driving View. You can also select a safety warning alert sound. Tap the **Alerts** button to select which speed cameras and safety-related features you want to be warned about. See [Settings for Speed Cameras Alerts](#) for more information.

Note: Information about speed cameras is not available in all countries. To find out if information about speed cameras is available in your country, go to tomtom.com/iphone.

Speed Limit

Adjust this setting to warn you when you are driving above the speed limit. You can also select a warning alert sound.

Important: It is important to pay attention to road signs and drive within the local speed limit. TomTom speed limit alerts should not be relied on exclusively while driving.

Places of Worship and Schools

Adjust this setting to warn you when you are driving near a place of worship, a school, a college or a university. The warning is not given when you are driving on a motorway, or between the hours of 20.00 and 06.00.

Traffic

Adjust this setting to switch on traffic warnings in the Driving View. You can also select a traffic warning alert sound.

Note: You only see this option when you have a subscription to TomTom HD Traffic.

Travel Via

Adjust this setting to switch all Travel Via alerts on or off.

Tip: To set the alert for each Travel Via stop, change the setting using Travel Via ([Find Alternative](#)).

Audio

Tap this option to set the following music and volume options.

Fade Music

Adjust this setting to fade the music when instructions and warnings are given.

When this setting is off, the music pauses instead of fading when instructions and warnings are given.

Voice Volume

Adjust this setting to set the volume of voice instructions as a percentage of the music volume.

For example, you can move the slider to the middle of the slider bar to set the volume of voice instructions at 50% of the music volume.

If the slider is set to off, the music volume and voice volume are set to the same level.

Map

Tap this option to set the following map options:

Day Colours / Night Colours

Tap **Day Colours** to select a day colour scheme consisting of bright colours.

Tap **Night Colours** to select a night colour scheme consisting of darker colours.

Auto-Switch automatically changes between day and night colours depending on the time of day.

Tap **Car Symbol** to select the car symbol that shows your current location in the Driving View.

2D Map North Up

When this setting is on, the 2D map is fixed in place with north at the top of the screen. When this setting is off, the 2D map moves so that your current direction is always at the top of the screen.

Show Current Street

When this setting is on, the current street name or number is shown in the Driving View, just below your position on the map.

Streets on Map

When this setting is on, street names are shown on the map.

POIs on Map

When this setting is on, POIs are shown on the map.

POI Types

Select which POIs are shown on the map.

Auto-Zoom

Auto-Zoom automatically adjusts the area of the map and level of detail shown in the Driving View. Switch off Auto-zoom to manually control the use of zoom in the Driving View.

Route planning

Adjust the Route planning settings to set how routes are planned.

Default Route Type

Adjust this option to set the type of route that will be planned when you plan a new route.

You can select the following types of route:

- **Fastest** - the fastest route to your destination.
- **Shortest** - the shortest route to your destination. This may take much longer than the fastest route.
- **Avoid Motorways** - this type of route avoids all motorways.
- **Walking Route** - this type of route is optimised for walking.
- **Bicycle Route** - this type of route is optimised for bicycles.
- **Limited Speed** - if you select this type of route, you must enter a maximum speed for your vehicle. The route planned takes this restriction into account.
- **Eco Route** - always plan the most fuel-efficient route.
- **Always Ask Me** - if you select this option, you will always be asked to select the type of route that should be planned.

You can set how each of the following road types is handled when a new route is planned:

- **Toll Roads**
- **Ferry Crossings**
- **Carpool Lanes**
- **Unpaved Roads**

You can set the following actions to be taken for each type of road:

- **Avoid** - the type of road is always avoided automatically.
- **Don't Avoid** - the type of road is not avoided automatically.
- **Always Ask** - when the route is planned, you have to select how to handle these roads when they occur on your route.

Distance Units

You can choose to use either Kilometres or Miles for all distances and speeds.

About

Tap **About** for information about the application and map version as well as copyright and the licence notices.

Advanced

Tap **Advanced** to adjust the following settings:

Multitasking

Adjust this setting to switch multitasking on and off.

Multitasking allows you to receive spoken instructions while using other applications and visual guidance while on phone calls.

Status bar

Adjust this setting to show or hide the status bar at the top of the Driving View. Hiding the status bar lets you see more of the map.

Lane Images

Adjust this setting to switch lane images on and off.

Lane images help you prepare for motorway exits and junctions by showing you which lane you should be in.

IQ Routes™

Adjust this setting to switch IQ Routes on and off.

IQ Routes is used when you plan a route. Your route is calculated using information about the real average speeds measured on roads, so your route may change depending on the time of day and day of the week.

Note: IQ Routes information is not available for all regions. For more information on IQ Routes, go to tomtom.com/iqroutes.

Data Services

Adjust this setting to switch the HD Traffic and Speed Cameras services on and off.

TomTom HD Traffic incidents are shown on the traffic sidebar and in the Browse Map screen, and traffic delays are taken into account when you plan a new route.

TomTom Speed Cameras updates the locations and speed limits of fixed cameras, and provides live updates for mobile camera locations.

Note: TomTom HD Traffic and Speed Cameras are TomTom subscription services which are only available in supported countries. For more information on TomTom HD Traffic, Speed Cameras and other services in your country, go to tomtom.com/iphone.

Camera Report Button

Adjust this setting to show or hide the Speed Camera reporting button in [The Driving View](#).

Map Share™

Adjust this setting to turn Map Share on and off. TomTom Map Share helps you correct map errors and share map corrections with the rest of the TomTom Map Share community.

Note: When this setting is adjusted the map is reloaded so that map corrections can be applied or removed. This may take several seconds.

Route Summary

Adjust this setting to **ON** to automatically close the Route Summary screen after 10 seconds.

GPS Enhancer™

Adjust this setting to switch the TomTom GPS Enhancer on and off.

The GPS Enhancer helps TomTom App to find your location more accurately.

Reset

Tap **Reset** to remove the following information:

Reset to Defaults

Tap this setting to restore the factory settings to TomTom App.

All your personal settings will be deleted, including your Favourites and your Home location.

Map Share™

Tap **Downloaded Map Corrections** to remove map corrections that you have downloaded from TomTom.

Tap **My Map Corrections** to remove map corrections that you have made yourself.

My Locations

Tap **Recent Destinations** to remove your recently visited locations from the location selector.

Tap **Favourites** to remove all your favourite locations.

Note: To delete favourites one at a time, tap **Manage Favourites** in the Change Settings menu. See [Deleting a Favourite](#) for more details.

Main Menu

The Main Menu

When you start TomTom App without having earlier planned a route, the Main menu is shown.

To open the Main menu from the Driving View, tap the screen.

The following buttons are available in the Main menu:



Navigate To...

Tap this button to start planning a route.



Route Options

Tap this button to find out more information about your route, or change the route.

Note: This button is only shown if a route is planned.



Browse Map

Tap this button to browse the map in the same way as you might look at a traditional paper map.



TomTom Shop

Tap this button to go to the TomTom Shop to purchase a TomTom HD Traffic subscription, a Speed Cameras subscription, or other navigation products and services.

If you have a TomTom HD Traffic or Speed Cameras subscription, you can tap this button to view your subscription status.



Advanced Planning

Tap this button to plan a route in advance, selecting your starting point and your destination.



Help Me

Tap this button to phone or drive to the nearest emergency services.

The Help Me menu also gives a description of your location so you can tell the emergency services where you are.



Tap this button to change how TomTom App behaves.

Change Settings

Navigate To menu

When you tap **Navigate To** in the Main menu, you can select your destination in the following ways:



Home

Tap this button to plan a route to your Home location.

To set your Home location, tap **Home** in the Settings menu.



Favourite

Tap this button to select a Favourite as your destination or to edit your favourites. See [Favourites](#) for more details.



Address

Tap this button to enter an address as your destination. To navigate to a postcode, tap the **Postcode** button at the top of the screen to display the Postcode screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



Recent Destination

Tap this button to select your destination from a list of places you have recently used as destinations. These also include your Travel Via stops.



Local Search

Tap this button to run an Internet search of the local area and use the location of one of the search results as your destination. See [TomTom Local Search with Google](#) for more details.



Point of Interest

Tap this button to navigate to a Point of Interest (POI).



Contact

Tap this button to plan a route to the address of a contact in your address book.



Photo

Tap this button to select a photo from your iPhone gallery and use it as your destination.

Note: Only photos that contain location data can be used. This feature can be enabled in the iPhone Camera application.



Postcode

Tap this button to enter a postcode as your destination. To navigate to an address, tap the **Address** button at the top of the screen to display the Address screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



Point on Map

Tap this button to select a point on the map as your destination using the Map Browser. See [Browse Map](#) for more details.



Coordinates

Tap this button to enter the map coordinates of a location on the map as your destination.

Return to Driving View




Many menus and screens have a quick access button to return you to the Driving View without having to step back through menus. The button appears in the top right corner of the screen.

Browse Map

Browsing a Map

Tap **Browse Map** in the Main menu to open the Map Browser. Using the Map Browser you can browse the map in the same way as you might look at a traditional paper map.



You can move around the map by using your finger to drag the map across the screen.

Zoom in and out by pinching your fingers together and apart on the screen. You can also zoom by tapping the screen twice with one finger to zoom in, or tap once with two fingers at the same time to zoom out.

Markers

Markers are placed on the map to show the distance to various locations. Tap a marker to centre the map on the marker location. Markers point toward one of the following locations:

- Your current location.
- Your home location.
- Your destination.


To set your own marker, position the cursor over the required location on the map, then tap the cursor button and then tap **Set marker position**.

Selecting Items on the Map

Tap the map to place the cursor at the location you tap.

You can also drag the cursor around the map by holding your finger on it until it expands. When you drag the cursor, the area within the expanded cursor is magnified.

When you place the cursor, a part of the map is selected. Details of this location are shown, along with an arrow.



Tap the location to use the cursor position. You can choose from the following options:



Navigate There

Tap this button to plan a route from your current location to the cursor position.



Travel Via...

Tap this button to travel via the cursor position on the route that is currently planned. This option is only shown if you have already planned a route.



Local Search

Tap this button to do a local search and plan a route to a location.



Find POI Nearby

Shows a list of POIs near the selected location, and also allows you to search for POIs.



POI Details

Shows the details of the POI you selected. You only see this option when you have selected a POI.



Call...

Tap this button to call a POI at the cursor position. You only see this option when you have selected a POI with a phone number.



Add as Favourite

Tap this button to add the cursor position as a Favourite. You have to give the Favourite a name.



Tap this button to place a marker at the cursor position.

Set Marker Position



Tap this button to move the map so that the cursor position is in the centre of the screen. The map zooms in on the cursor position.

Centre on Map

Map Toolbar

The toolbar at the bottom of the Browse Map screen has the following buttons:



Tap this button to centre the map on your current location.



Tap this button to show your route on the map.



Tap this button to show traffic incidents in the Map Browser. TomTom HD Traffic is a subscription service.



Tap this button to open the map corrections menu. This button is only available when a road is selected. See [Map Corrections with TomTom Map Share™](#) for more details.



Tap this button to search for a location on the map. Select the location in the same way as you select a destination when planning a journey. The cursor then moves to the selected location.



Tap this button to select the information shown on the map. You can select to show the following information:

- **Traffic**
- **Favourites**
- **Names**
- **Coordinates**
- **Points of Interest**

Tap **POI Types** to select which POIs are shown on the map.

Map Corrections with TomTom Map Share

About TomTom Map Share

TomTom Map Share helps you correct map errors and share map corrections with the rest of the TomTom Map Share community.

You can correct your map and share map corrections with other Map Share users using **Browse Map** in the Main menu.

Note: TomTom Map Share is not available in all regions. For more information, go to tomtom.com/mapshare.

On an iPod touch or iPad without 3G, TomTom Map Share only connects to the TomTom Map Share community when there is a WiFi connection. Changes you make while not connected are shown only on your TomTom App and are not uploaded even when you later connect via WiFi.

Map corrections

Map corrections are reported by Map Share users. Some are shared with other community members immediately and some are first verified by TomTom.

- Corrections that are reported by Map Share community members include changes to the traffic flow in a street, blocking or renaming a street, and adding, removing or editing POIs.
These corrections are immediately shared with the Map Share community.
- Corrections that are reported by Map Share members and verified by TomTom include missing streets, new speed cameras, errors in motorway entrances and exits, and missing roundabouts.
These corrections are investigated and verified by TomTom and are included when the next map version is released.

Switching Map Share on and off

TomTom Map Share is automatically enabled when you start TomTom App and a welcome message is displayed.

If you want to stop using Map Share, tap **Change Settings** in the Main menu, then **Advanced**. Adjust the **Map Share** setting to turn Map Share off or on.

Note: When this setting is adjusted the map is reloaded so that map corrections can be applied or removed. This may take several seconds.

Downloading and sending map corrections

After the welcome message, you are asked if you want to download any map corrections that are available from other TomTom users. Map Share then checks for new corrections on a weekly basis.

Tip: The size of the download for the map corrections is shown.

To change your download settings, do the following:

1. Tap **Change Settings** in the main menu
2. Tap **Map** to show the Map menu.
3. Tap **Map Share Update**.
 - Tap **Get Corrections** to choose whether you want to download corrections automatically, manually or after being asked.
 - Switch on **WiFi Only** if you only want map corrections to be downloaded when you are connected to a wireless network.
 - Tap **Check for New Corrections** to see if there are more corrections to download at any time.

Note: All the corrections that you make to your own map are shared and automatically sent to TomTom.

Reporting a map error

To correct a map error, do the following:

1. Tap **Browse Map** in the Main menu.
2. Select the location you want to correct on the map.
3. On the Browse Map toolbar, tap the map corrections button.



4. Select the type of map correction you want to report.
5. Enter the details of the correction, then tap **Send**.
The correction is saved and the information is sent to the TomTom Map Share team.
6. A Thank You message appears. Tap **Continue** to return to the Browse Map screen.

Types of map correction

The following types of map correction are available.



(Un)block Street

Tap this button to block or unblock a street. You can block or unblock the street in one or both directions.
Tap one of the buttons at the bottom of the screen to make the street two-way, one-way or blocked.



Edit Street Name

Tap this button to change the name of the street using your keyboard.

Note: You are asked if you want to change the name of the whole street or only for the section that you selected.



Change Speed Limit

Tap this button to change the speed limit of the **Whole road**, the **Current speed zone** or for **Only selected section**.



Report Other Error

Tap this button to report other types of corrections to TomTom.

Type a message describing the correction. For example, you can report missing streets, errors in motorway entrances and exits or missing roundabouts. Tap **Send** and TomTom App sends a special report to TomTom Map Share.



Report Speed Camera

Tap this button to report a Speed Camera. You can choose to report a **Fixed Camera** or a **Mobile Camera**.

The location on the map appears. Tap **Done** to report the camera.

A **Thank you** message appears. Tap **Close**.

Points of Interest (POIs)

About POIs

Points of Interest or POIs are useful places on the map.

Here are some examples:

- Restaurants
- Hotels
- Museums
- Parking garages
- Petrol stations

There are several places where you can use POIs in TomTom App:

- Selecting a POI as your destination when planning a route.
- Calling a POI from the map browser.
- Selecting which POIs to show on the map.

Navigating to a POI

You can select a POI as your destination or as a Travel Via location.

When calling a POI or navigating to a POI, select the POI in the following way:

1. Tap the screen to show the Main menu.
2. If you want to navigate to a POI, tap **Navigate To...** then tap **Point of Interest**.
3. If you have already planned a route and want to add a POI as a Travel Via location, tap **+1** on the Route Summary screen then tap **Point of Interest**.
4. Narrow your choice of POIs by selecting the area where the POI is located.

The following options are available:



POI Near Me

Tap this button to choose from a list of POIs near to your current location.



POI in City

Tap this button to find a POI in a particular town or city.



Tap this button to choose from a list of POIs near to your Home location.

POI Near Home

The following options are available when a route is already planned:



Tap this button to find a POI along your planned route.

POI Along Route



Tap this button to find a POI near your planned destination.

POI Near Destination

5. If you selected **POI in City**, type the name of the town you want to visit and select the town when it appears in the list.
6. Select the category of POI.
Tap **Search** to search to look for a POI by name. All POIs in all categories are searched.
Tap the category of the POI, if it is shown.
Tap **More** to choose from the complete list of categories. Select the category from the list.
7. From the list of POIs shown, select the POI you want to navigate to.

The table below explains the distances listed next to each POI.

POI Near You	Distance from your current location
POI in City	Distance from the city centre
POI Near Home	Distance from your Home location
POI Along Route	Distance from your current location
POI Near Destination	Distance from your destination

If you have planned a route, a symbol is also shown next to each POI.



POI is on your route



POI is close to your route



POI is fairly close to your route.



POI is off your route.

After you select a POI, detailed information such as the phone number and a short description is shown. Depending on the POI information available and the functions on your Apple device, tap a panel to phone or email the POI, or open the POI's website.

Tap **Select** to confirm you want to plan a route to this POI.

Finding a POI on the Map Browser

You can find a POI using the Map Browser then contact the POI or navigate to it.

1. Tap the screen to show the Main menu.
2. Tap **Browse Map**. Make sure **Points of Interest** are selected in the Map Details page. You can also select which POIs to show on the map. See [Browse Map](#) for more details.
3. Find a POI on the map. You can display your route so you can find POIs along your route, and zoom in and move the map.
4. Select a POI symbol then tap the POI name panel to display the POI menu.

The following options are available:



Tap this button to plan a route from your current location to the cursor position.

Navigate There



Tap this button to travel via the cursor position on the route that is currently planned. This option is only shown if you have already planned a route.

Travel Via...



Tap this button to do a local search and plan a route to a location.

Local Search



Shows a list of POIs near the selected location, and also allows you to search for POIs.

Find POI Nearby



Shows the details of the POI you selected. You only see this option when you have selected a POI.

POI Details



Tap this button to call a POI at the cursor position. You only see this option when you have selected a POI with a phone number.

Call...



Tap this button to add the cursor position as a Favourite. You have to give the Favourite a name.

Add as Favourite



**Set Marker
Position**

Tap this button to place a marker at the cursor position.



Centre on Map

Tap this button to move the map so that the cursor position is in the centre of the screen. The map zooms in on the cursor position.

Showing POIs on the map

POIs can be shown on the map in the Driving View and in the Map Browser.

To show POIs in the Driving View, do the following:

1. Tap **Change Settings** in the Main menu.
2. Tap **Map**.
3. Make sure that the setting **POIs on Map** is selected.

To show POIs on the map in the Map Browser, do the following:

1. In the Main menu, tap **Browse Map**.
2. Tap the information button in the bottom right-hand corner of the screen to show the Map Details screen.
3. Make sure that the setting **Points of Interest** is selected.

Selecting which POIs to show on the map

You can select the categories of POIs that are shown, for example, petrol stations, restaurants and hotels.

The selection you make is used for both maps.

To change the POI categories shown in the Driving View, do the following:

1. Tap **Change Settings** in the Main menu.
2. Tap **Map**.
3. Tap **POI Types**.
4. Select which POIs you want to be shown on the map.

To change the POI categories that are shown in the Map Browser, do the following:

1. Tap **Browse Map** in the Main menu.
2. Tap the information button in the bottom right-hand corner of the screen.
3. Tap **POI Types**.
4. Select which POIs you want to be shown on the map.

Help Me

About Help Me

Help Me provides an easy way to navigate to emergency services centres and other specialist services and contact them by phone.

For example, if you are involved in a car accident, you could use **Help Me** to call the nearest hospital and tell them your exact location.

Using Help Me to phone a local service

You can use **Help Me** to search for a service centre, make contact by phone and inform the centre about the precise details of your current location.

When you search for a service centre, you are shown a list of nearby locations. Select one of the centres in the list to view their address and phone number and your current location on the map.

To use **Help Me** to locate a service centre, contact the centre by phone and navigate from your current location to the centre, do the following:

1. Tap the screen to bring up the Main menu.
2. Tap **Help Me**.
3. Tap **Phone for Help**.
4. Select the type of service you require, for example, Nearest hospital.
5. To dial, select a centre from the list, the nearest is shown at the top of the list.

If your device has a phone feature, you can tap the button showing the phone number to dial it immediately. If your device does not have a phone feature, you are shown the number so you can dial using another device.

Once the call is answered, for a description of your current location, open TomTom App again and tap **Help Me**. A description of your current location is shown. Tap the description to copy the text. You can then paste the description into a text message or email.

6. To navigate your way to the centre by car, tap **Drive to Help**.

TomTom App starts guiding you to your destination.

Favourites

About Favourites

Favourites are places that you often visit. You can create Favourites so that you don't have to enter the address every time you want to navigate there.

They do not need to be favourite places or even locations you often visit, they can simply be seen as a collection of useful addresses.

Creating a Favourite

You can create a Favourite from one of the following locations in TomTom App:

- using the **Navigate To...** menu and the **Favourite** menu
- using the **Change Settings** menu and the **Manage Favourites** menu
- from a location selected on the Map Browser. See [Finding a POI on the Map Browser](#) for more details.

To create a Favourite using the **Favourite** menu or **Manage Favourites** menu, tap the **+** symbol at the bottom of the screen. The Add Favourite screen appears showing the following buttons:



Address

Tap this button to enter an address as a favourite. To use a postcode, tap the **Postcode** button at the top of the screen to display the Postcode screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



Recent Destination

Tap this button to select a favourite location from a list of places you have recently used as destinations.



Local Search

Tap this button to run an Internet search of the local area and use the location of one of the search results as a favourite.



Point of Interest

Tap this button to add a Point of Interest (POI) as a favourite.



Contact

Tap this button to add a contact's address as a favourite.



Photo

Tap this button to select a photo from your iPhone gallery and use the location to create a favourite.

Note: Only photos that contain location data can be used. This feature can be enabled in the iPhone Camera application.



Postcode

Tap this button to enter a postcode as a favourite. To use an address, tap the **Address** button at the top of the screen to display the Address screen.

Note: You only see **Postcode** when your map includes the UK or the Netherlands. You can only navigate to a postcode in the UK or the Netherlands.



My Location

Tap this button to add your current position as a favourite.

For example, if you stop somewhere interesting, while you are there you can tap this button to create the Favourite.



Coordinates

Tap this button to enter the map coordinates of a location on the map as a favourite.

Give your Favourite a name that is easy to remember. TomTom App will always suggest a name. If you don't like the suggested name, delete it and enter a new one. You can always change the name later.

Tap **Done** to save the Favourite.

Using a Favourite

You will normally use a Favourite as a way of navigating to a place without having to enter the address. To navigate to a Favourite, do the following:

1. Tap the screen to bring up the Main menu.
2. Tap **Navigate To....**
3. Tap **Favourite**.
4. Select a Favourite from the list.

TomTom App calculates the route for you.

5. Tap **Done**.

TomTom App immediately starts guiding you to your destination using spoken instructions and on-screen directions.

Changing the name of a Favourite

To change the name of a Favourite do the following:

1. Tap the screen to show the Main menu.
2. Tap **Change Settings**.
3. Tap **Manage Favourites**.
4. Tap the Favourite you want to rename.

5. Tap **Name** on the Favourite, then enter the new name for the Favourite.
6. Tap **Done**.

The Favourite is renamed.

Changing the order of your Favourites

Change the order of your Favourites as follows:

1. Tap the screen to show the Main menu.
2. Tap **Change Settings**.
3. Tap **Manage Favourites**.
4. Tap **Edit**, then using the order symbol on the right of the Favourite drag the Favourite to its new position in the list.
5. Tap the **Done** button.

Deleting a Favourite

Delete a Favourite as follows:

1. Tap the screen to show the Main menu.
2. Tap **Change Settings**.
3. Tap **Manage Favourites**.
4. Delete a Favourite using one of the following methods:
 - Tap **Edit**, then tap the stop sign next to the Favourite you want to delete. Tap the **Delete** button, then tap the **Done** button.
 - Swipe across the Favourite. Tap the **Delete** button.

Traffic Information

TomTom HD Traffic

TomTom HD Traffic is a unique TomTom service providing real-time traffic information. Using the latest traffic information in combination with IQ Routes, TomTom HD Traffic helps you plan the optimum route to your destination. For more information about TomTom services and subscriptions, go to tomtom.com/iphone.

Important: TomTom HD Traffic is only supported for use with the iPhone and the iPad 3G and is not supported for use with the iPod touch or the iPad without 3G.

To use TomTom HD Traffic, you need a continuous data connection (GPRS, EDGE, UMTS or CDMA). Your mobile operator may charge you for using a wireless data connection.



TomTom App regularly receives information about the changing traffic conditions. If traffic jams or other incidents are found on your route, TomTom App can replan your route to minimise any travel delays.

Tip: TomTom App automatically downloads traffic updates and may incur mobile roaming charges when travelling abroad.

To prevent this, tap **Change Settings** in the Main menu, then tap **Advanced**, then scroll down to **Data Services** and tap the button to switch off the service.

Using traffic information

Tap the car in the top right-hand corner of the Driving View to show the traffic sidebar.

The traffic sidebar shows all the major traffic incidents as they occur on your route. Glowing dots show where the incidents are located on the route.



The car at the top of the traffic sidebar shows the total delay caused by traffic incidents on your route.

The central section of the traffic sidebar shows individual traffic incidents in the order they occur on your route.

The bottom of the traffic sidebar represents your current location.

Scroll the traffic sidebar up and down using your finger to see all the traffic incidents on your route.

As the traffic sidebar scrolls, it stops moving when it reaches the next incident.

To improve visibility on the traffic sidebar, some minor incidents may not be shown.

The total delay caused by traffic incidents on your route is shown using different coloured cars at the top of the traffic sidebar.



There is no delay on your route.



Less than 15 minutes delay on your route.



More than 15 minutes delay on your route.



Traffic service updating.



No route planned, traffic is up to date.



No subscription to TomTom Traffic.



Traffic service is unavailable.


Getting more information about an incident

When a traffic incident is shown on the map, the starting point of the incident is indicated with a traffic symbol.



As you scroll the traffic sidebar up and down, the panel above the status bar shows more information about each incident. This includes the type of incident, such as road works, and the delay caused by this incident.

Tap the panel to view more information about the incident.



Tap the up and down arrow buttons to view separate incidents in the order they occur on your route.

Tap **Minimise Delays** to check whether you can save time by using an alternative route.

Taking the fastest route

TomTom App constantly looks for changes in the traffic on your route and checks if there is a faster route to your destination. If a faster route is found, you are asked if you want to use the faster route.

To check if you are using the fastest route, do the following:

1. Tap the screen to open the Main menu.
2. Tap **Route Options**.
3. Tap **Minimise Delays**.



Tip: This button is only available if you have a subscription to TomTom Traffic.

If a faster route is found you are asked if you want to use the new route.

Checking traffic incidents in your area

For an overview of traffic incidents in your area and to view the details, do the following:

1. Tap Browse map in the Main menu.
The map is shown.
2. Tap the traffic button in the status bar to show traffic incidents on the map.
The map shows traffic incidents in your area.



3. Tap on a traffic incident for detailed information.
The incident viewer opens and shows you detailed information about the incident.







Traffic incidents

Traffic incidents and warnings are shown on the map, in the Driving View and on the traffic sidebar.






There are two types of incident and warning signs:

- Symbols shown in a red square are traffic incidents. TomTom App can replan your route to avoid new incidents.
- Symbols shown in a red triangle are weather-related. TomTom App is unable to replan your route to avoid these warnings.

Traffic incident symbols:

	Accident
	Road works
	One or more lanes closed
	Road closed
	Traffic incident
	Traffic jam

Weather-related symbols:

	Fog
	Rain
	Wind
	Ice
	Snow

Regional availability

Note: You can use TomTom services when travelling abroad, but when planning a route you need to consider that not all services are available in all countries.

For more information on available services, go to tomtom.com/iphone.

Buying a new Traffic subscription

To buy a new subscription, do the following:

1. Start TomTom App.
2. Tap **TomTom Shop** in the Main Menu to open the TomTom Shop.
3. Tap **Traffic**.
4. Choose a subscription from the list of TomTom HD Traffic subscriptions.
5. Create a new TomTom account or login to your existing TomTom account.

Tip: If you already own a TomTom navigation device, then we recommend that you open a new TomTom account for your iPhone using a different email address.

For more information on MyTomTom accounts, go to tomtom.com/mytomtom.

Your purchase is completed in the Apple App Store. If payment is successful, TomTom HD Traffic starts within a few minutes on your TomTom App.

Checking your Traffic subscription

You can check the status of your subscription at any time, by tapping **TomTom Shop** in the Main menu, then tapping **Traffic**.

TomTom App also warns you when your subscription is approaching the renewal date.

Renewing your Traffic subscription

You can renew your TomTom HD Traffic subscription after it has expired or extend it before it reaches its expiry date.

To renew an expired subscription, do the following:

1. Start TomTom App.
2. Tap **TomTom Shop** in the Main Menu to open the TomTom Shop.
3. Tap **Traffic**.
4. Choose the subscription you want to renew.
5. Login to your existing TomTom account.


Tip: For more information on MyTomTom accounts, go to tomtom.com/mytomtom.

Your purchase is completed in the Apple App Store. If payment is successful, TomTom HD Traffic starts within a few minutes on your TomTom App.

Speed Cameras

About Speed Cameras

The Speed Cameras service shows you information about both fixed and mobile speed cameras, average speed cameras, traffic control cameras and dangerous road features along your route. The information shown by the Speed Cameras service is continually updated by TomTom users and frequently sent to your TomTom App so you always have the latest information for your route. You can also add or remove speed cameras.



Important: The Speed Cameras service is only available for use with the iPhone and iPad 3G and is not available for the iPod touch or the iPad without 3G.

To use Speed Cameras you need a continuous data connection (GPRS, EDGE, UMTS or CDMA). Your mobile operator may charge you for using a wireless data connection. To stop the Speed Cameras service updating, tap **Change Settings** in the Main menu, then tap **Advanced**, then scroll down to **Data Services**. Tap the button to switch off the service.















Types of speed cameras and safety-related features











The Speed Cameras service shows you warnings in [The Driving View](#) when there is a speed-camera or safety-related feature on your driving route. You are warned that a speed camera is on your route 15 seconds before you reach it. You can select the safety-related features you want to be warned about in [Alerts](#).

When you receive a warning, an alert symbol appears in the top left corner of The Driving View, and a small symbol appears on your driving route. Where the speed limit is relevant it is shown in the alert symbol. The distance to the feature is shown at the bottom of the alert symbol.

The alert symbol has a green background border when you are driving at or slower than the speed limit, and a red background border when you are driving faster than the speed limit. Tap the alert symbol to cancel the Speed Cameras warning.

Speed Cameras warns of the following types of cameras and safety-related road features:





Alert symbol	Route symbol	Description
		Fixed location speed camera
		Traffic light camera This can be a camera with or without speed detection.
		Miscellaneous speed camera
		Bidirectional speed camera A camera that can measure speed in both directions.
		Mobile speed camera TomTom App remembers mobile speed cameras for three hours after you report them.
		Toll road camera
		Restricted-road safety camera These cameras check for vehicles that use restricted roads, for example a road that is not permitted to be used during rush hour.

		<p>Mobile camera hotspot</p> <p>These are areas in which there have been many reports of mobile speed cameras being used.</p>
		<p>Average speed cameras - start of zone warning.</p> <p>You get a warning every 200 metres when you are driving in the average speed zone. If you drive at or below the speed limit no warning sound is given. If you drive above the speed limit you hear a warning sound.</p>
		<p>Average speed cameras - end of zone warning.</p>
		<p>Accident blackspot</p> <p>These are areas where there have been many accidents.</p>
		<p>Ungated level crossing</p>

Frequency of speed camera updates

Your Speed Cameras service is constantly being updated unless the connection to the TomTom server is lost.

You can see if the service is currently receiving updates from the TomTom server by looking at the colour of the speed camera symbols in the Driving View:

		<p>When the Speed Cameras service is receiving updates from TomTom, the 'distance to camera' part of the camera alert symbol is blue and the symbol shown on your route is also blue.</p>
		<p>When the Speed Cameras service is not able to receive updates from the TomTom server, the 'distance to camera' part of the camera alert symbol is grey and the symbol shown on your route is black.</p>

Your Speed Cameras service may not be receiving updates from TomTom due to one or more of the following reasons:

- Your subscription has expired. See [Checking your Speed Cameras subscription](#).
- The Speed Cameras service is switched off. See [Advanced](#).
- Speed Cameras are not available in your area. For more information on Speed Cameras and other services in your country, go to tomtom.com/iphone.

Report a speed camera



Tap this symbol to report a speed camera. The message **Thank you for reporting a speed camera** is shown at the top of the screen. The location is reported to TomTom and shared with other TomTom navigation device users with a Speed Cameras subscription.

Note: A reported speed camera stays in TomTom App for three hours.

Remove a speed camera



The speed camera symbol changes to this symbol when you are near a speed camera. Tap the symbol to remove a mobile speed camera. You can remove a speed camera until 5 seconds after you have passed its location. The removal is reported to TomTom and shared with other TomTom App Speed Cameras subscribers.

Regional availability

Note: You can use TomTom services when travelling abroad, but when planning a route you need to consider that not all services are available in all countries.

For more information on available services, go to tomtom.com/iphone.

Settings for Speed Cameras Alerts

The Speed Cameras Alert settings let you turn the Speed Cameras alert on or off, and let you select the alert sound.

1. In the **Main Menu**, tap **Change Settings**.
2. Tap **Alerts**.
3. In the **Speed Camera** box set the following settings:
 - Tap the button to turn speed camera alerts on or off.
 - Tap **Sounds** and choose a sound for the alert.
 - Tap **Types** and select which speed cameras and safety-related items you want to receive a warning for. See [Types of speed cameras and safety-related features](#) for more information.

Buying a new Speed Cameras subscription

To buy a new subscription, do the following:

1. Start TomTom App.
2. Tap **TomTom Shop** in the Main Menu to open the **TomTom Shop**.
3. Tap **Speed Cameras**.
4. Choose a subscription from the list of Speed Camera services.

5. Create a new TomTom account or login to your existing TomTom account.

Tip: If you already own a TomTom navigation device, then we recommend that you open a new TomTom account for your iPhone using a different email address.

For more information on MyTomTom accounts, go to tomtom.com/mytomtom.

Your purchase is completed in the Apple App Store. If payment is successful, Speed Cameras starts within a few minutes on your TomTom App.

Checking your Speed Cameras subscription

You can check the status of your subscription at any time, by tapping **TomTom Shop** in the Main menu, then tapping **Speed Cameras**.

When you have 7 days or less before your subscription expires, TomTom App shows a message to warn you that your subscription is approaching the renewal date. This message is repeated when you have one day left on your subscription.

After your subscription has expired the Speed Cameras service is deleted from TomTom App.

The colour of the camera symbols in the Driving View indicates whether your Speed Cameras service is connected to the TomTom server. See [Frequency of speed camera updates](#) for more details.

Renewing your Speed Cameras subscription

You can renew your Speed Cameras subscription after it has expired or extend it before it reaches its expiry date.

To renew an expired subscription, do the following:

1. Start TomTom App.
2. Tap **TomTom Shop** in the Main Menu to open the TomTom Shop.
3. Tap **Speed Cameras**.
4. Choose the subscription you want to renew.
5. Login to your existing TomTom account.

Tip: For more information on MyTomTom accounts, go to tomtom.com/mytomtom.

Your purchase is completed in the Apple App Store.

TomTom Local Search with Google

About TomTom Local Search with Google

You can use **Local Search** to find shops and businesses and plan a route to the store or office location.



Local Search has the following search options:



Tap this button to search near your current location.

Search near Me



Tap this button to search in a particular city.

Search in City



Tap this button to search near your Home location.

Search near Home



Tap this button to search near your destination.

Search near Destination

Note: Local Search requires a WiFi network or a wireless data connection (GPRS, EDGE, UMTS or CDMA). Your mobile operator may charge you for using a wireless data connection. Using Local Search when travelling abroad may cost you more than when you use the service at home.

Using local search

To use local search to plan a route, do the following:

In this example, you will search for a restaurant near to your current location.

1. Tap the screen to open the Main menu, then tap **Navigate to**.

2. Tap **Local search**.
3. Tap **Search near me**.
4. Type 'restaurant', then tap **Done**.

The locations that match your search are shown in a list.

5. Tap one of the locations in the list.

The location is shown on the map together with the address, Google rating, phone number and additional information.

You can tap the map to show it full screen.

6. Tap **Select** to plan a route to the location.

TomTom App plans a route to the location.

You can also tap on the phone number to call the restaurant or tap the internet address to visit the website.

Tip: When you select a phone number to make a call, TomTom App will close on devices that do not support multi-tasking.

'Add to TomTom'

About 'Add to TomTom'

The **'Add to TomTom'** button is shown on websites including those for supermarkets, cinemas and tourist attractions.

When you see the **'Add to TomTom'** button on a website, you can click the button to view the location in TomTom App.

For example, if your favourite restaurant has an **'Add to TomTom'** button on their website, click the button to show the restaurant location on the map.

Using the 'Add to TomTom' button

Use the **'Add to TomTom'** button as follows:

1. Using your iPhone, go to a website that has an **'Add to TomTom'** button.
2. Click the **'Add to TomTom'** button.

TomTom App starts and, depending on what the **'Add to TomTom'** button is designed to do, one of the following actions occurs:

- The location is shown on the map.
- A route from your current location is calculated.
- The location is added as a Favourite or Point of Interest.

Addendum and Copyright

Important Safety Notices and Warnings

Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the globe. GPS is operated and controlled under the sole responsibility of the Government of the United States of America which is responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your TomTom device. TomTom does not accept any liability for the availability and accuracy of GPS.

Use with Care

Use of a TomTom device for navigation still means that you need to drive with due care and attention.

Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. A TomTom device must not be used in these environments.

SPECIAL NOTE REGARDING DRIVING IN CALIFORNIA AND MINNESOTA

California Vehicle Code Section 26708 (a) (1) provides that "No persons shall drive any motor vehicle with an object or material placed, displayed, installed, affixed or applied upon the windshield or side or rear windows." Drivers in California should not use a suction mount on their windshield, side or rear windows.

Note: This section of the California Vehicle Code applies to anyone driving in California, not just California residents.

Minnesota State Legislature Statutes Section 169.71, subdivision 1, section 2 provides that "A person shall not drive or operate with any objects suspended between the driver and the windshield other than sun visors and rearview mirrors and electronic toll collection devices."

Note: this Minnesota Statute applies to anyone driving in Minnesota, not just Minnesota residents.

TomTom Inc. bears no responsibility for any fines, penalties or damage that may be incurred by disregarding this notice. While driving in any state with windshield mounting restrictions, TomTom recommends the use of the supplied Adhesive Mounting Disk or its Alternative Mounting Kit, which includes multiple options for mounting TomTom devices on the dashboard and the air vents. See tomtom.com for more information about these mounting options.

This Document

Great care was taken in preparing this manual. Constant product development may mean that some information is not entirely up to date. The information in this document is subject to change without notice.

TomTom shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the performance or use of this material. This document contains information protected by copyright. No part of this document may be photocopied or reproduced in any form without prior written consent from TomTom N.V.

Copyright notices

© 2011 TomTom. All rights reserved. TomTom and the TomTom logo are registered trademarks of TomTom N.V. Please see tomtom.com/legal for warranties and end user licence agreements applying to this product.

© 2011 TomTom. All rights reserved. This material is proprietary and the subject of copyright protection and/or database right protection and/or other intellectual property rights owned by TomTom or its suppliers. The use of this material is subject to the terms of a license agreement. Any unauthorized copying or disclosure of this material will lead to criminal and civil liabilities.

Ordnance Survey © Crown Copyright Licence number 100026920.
Data Source © 2011 TomTom
All rights reserved.

Some images are taken from NASA's Earth Observatory.

The purpose of NASA's Earth Observatory is to provide a freely-accessible publication on the Internet where the public can obtain new satellite imagery and scientific information about our home planet. The focus is on Earth's climate and environmental change: earthobservatory.nasa.gov

The software included in this product contains copyrighted software that is licenced under the GPL. A copy of that licence can be viewed in the Licence section. You can obtain the complete corresponding source code from us for a period of three years after our last shipment of this product. For more information, visit tomtom.com/gpl or contact your local TomTom customer support team via tomtom.com/support. Upon request, we will send you a CD with the corresponding source code.

Linotype, Frutiger and Univers are trademarks of Linotype GmbH registered in the U.S. Patent and Trademark Office and may be registered in certain other jurisdictions.
MHei is a trademark of The Monotype Corporation and may be registered in certain jurisdictions.

Compatible with all iPhone models

"Works with iPhone" means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Made for iPod touch

"Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

Made for iPad

"Made for iPad" means that an electronic accessory has been designed to connect specifically to iPad and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

iPad is a trademark of Apple Inc., registered in the U.S. and other countries.